

ESSENTIAL ENERGY ABSORBING TWISTED ROPE FORKED LANYARD WITH STEEL SCAFFOLD HOOKS AND KARABINER

KStrong has developed a range of Twisted Rope Energy Absorbing Lanyards to ensure the user is protected when working at heights. The Shock absorber effectively arrests a fall, minimising the forces to the body. Each lanyard has been hand spliced and the robust construction ensures it can be used in all environments.

FEATURES

- 12mm Twisted Rope
- Twist Lock Karabiner
- Scaffold Hooks
- Label Pack
- Energy Absorber
- Abrasion Resistant Thimbles
- Compass Asset Technology

HOW TO USE

Refer to User Instruction Manual



SCAN TO DOWNLOAD

MATERIAL COMPONENTS

Twisted Rope:	12mm 3 strand Polyamide Twin Twisted Rope, MBS 25kN
Metal Components:	Karabiners (AFC601100) Steel, MBS 25kN Scaffold Hook (AFC608111) Steel, MBS 23kN
Stitching Thread:	High Tenacity Polyester (Colour Contrasted)
Energy Absorber:	44mm Polyester Back Up Webbing 44mm Polyamide Tear Webbing

WEIGHT

1.95kg

LENGTH

1.8m

CAPACITY

100kg

RELEVANT STANDARDS

EN 355:2002 & VG11/RfU

